
Audio System Handbook Supplement

XK series

JJM 10 03 14/101

Published August 2001 by Parts and Service Communications Jaguar Cars Limited

Audio System Handbook (convertible models with Premium Audio System only)

Section 1. Introduction and controls

FADE Disable

Your Jaguar vehicle Audio System has a frontal sound stage designed to simulate an auditorium with the stage in front of the listener. System low frequency response (deep bass) is provided by 6.5 inch (165 mm) diameter sub-woofer speakers installed in the rear quarter trim panels.

On all convertible models fitted with the Premium Audio System, the FADE function referred to on page 1-5 of the Audio System Handbook is disabled at the factory.

Whilst Jaguar Audio Engineering recommends that FADE control is kept in this disabled condition, it can if desired, be re-enabled in the radio set-up mode as follows:

1. Simultaneously press the cassette eject and AM/FM buttons.
2. Pressing preset button **9** will then toggle between FADE ENABLE and FADE DISABLE as shown on the audio display panel.
3. To exit set-up mode, simultaneously press the cassette eject and AM/FM buttons. If the exit set-up procedure is not adopted within 15 seconds of selecting FADE enable or disable, the audio display will automatically clear and the system will return to the previous setting.

Note: If the audio system is set to FADE ENABLED and the sound is then faded to the rear, it should be noted that only low frequency sounds will be heard.